

7-1-07

LIFE LINE NETTING INSTRUCTIONS

Thank you for choosing Johnson's new knotless life line netting. Installation is easy. Take the time to layout the netting for a consistent diamond pattern.

1. Start aft and work forward. Fasten netting to either aft railing or desired stanchion. Lash vertically as shown in X with 1/8" cord or fasten with nylon ties.
2. Weave upper life line wire through netting or fasten with nylon ties.
3. If your boat has an aluminum toe rail, lash with 1/8" cord or fasten with nylon ties. If no toe rail, run a 1/4" foot rope from stanchion to stanchion and weave or fasten netting with nylon ties.
4. Working forward, finish the system by hot-knifing the ends about 6 inches beyond the bow pulpit and lash as shown in Y or fasten with nylon ties.

Enjoy your new netting!

